

TRANSFORMER EQUATION PHYSICS

THE FUNDAMENTAL TRANSFORMER EQUATION: UNPACKING THE PHYSICS OF VOLTAGE TRANSFORMATION

TRANSFORMER EQUATION PHYSICS IS THE BEDROCK UPON WHICH MODERN ELECTRICAL POWER DISTRIBUTION AND ELECTRONICS ARE BUILT. UNDERSTANDING THESE FUNDAMENTAL PRINCIPLES ALLOWS US TO MANIPULATE VOLTAGE LEVELS EFFICIENTLY, A PROCESS CRITICAL FOR EVERYTHING FROM POWERING OUR HOMES TO THE INTRICATE WORKINGS OF OUR DIGITAL DEVICES. THIS ARTICLE WILL DELVE DEEP INTO THE CORE TRANSFORMER EQUATION, EXPLORING ITS DERIVATION, THE KEY VARIABLES INVOLVED, AND HOW IT GOVERNS THE BEHAVIOR OF THESE INDISPENSABLE ELECTROMAGNETIC DEVICES. WE'LL DISSECT THE RELATIONSHIP BETWEEN TURNS RATIO, VOLTAGE, AND CURRENT, AND EXAMINE THE IDEAL CONDITIONS UNDER WHICH THESE EQUATIONS HOLD TRUE. FURTHERMORE, WE WILL TOUCH UPON THE PRACTICAL IMPLICATIONS AND HOW SLIGHT DEVIATIONS FROM THE IDEAL CAN IMPACT REAL-WORLD TRANSFORMER PERFORMANCE. PREPARE TO UNLOCK THE SECRETS OF ELECTROMAGNETIC INDUCTION AND ITS APPLICATION IN VOLTAGE TRANSFORMATION.

TABLE OF CONTENTS

- UNDERSTANDING ELECTROMAGNETIC INDUCTION: THE FOUNDATION OF TRANSFORMERS
- THE CORE TRANSFORMER EQUATION: VOLTAGE RELATIONSHIP
- THE ROLE OF THE TURNS RATIO
- THE TRANSFORMER EQUATION FOR CURRENT
- IDEAL VS. REAL TRANSFORMERS: DEVIATIONS AND PRACTICAL CONSIDERATIONS
- APPLICATIONS OF TRANSFORMER EQUATIONS IN POWER SYSTEMS

UNDERSTANDING ELECTROMAGNETIC INDUCTION: THE FOUNDATION OF TRANSFORMERS

BEFORE WE CAN TRULY GRASP THE TRANSFORMER EQUATION, IT'S CRUCIAL TO UNDERSTAND THE PHYSICAL PHENOMENON THAT MAKES TRANSFORMERS WORK: ELECTROMAGNETIC INDUCTION. DISCOVERED BY MICHAEL FARADAY, THIS PRINCIPLE STATES THAT A CHANGING MAGNETIC FIELD WILL INDUCE AN ELECTROMOTIVE FORCE (EMF), OR VOLTAGE, IN A CONDUCTOR. IN A TRANSFORMER, THIS IS ACHIEVED THROUGH TWO COILS OF WIRE, KNOWN AS THE PRIMARY AND SECONDARY WINDINGS, TYPICALLY WOUND AROUND A COMMON FERROMAGNETIC CORE. WHEN AN ALTERNATING CURRENT (AC) FLOWS THROUGH THE PRIMARY WINDING, IT CREATES A CONSTANTLY CHANGING MAGNETIC FLUX WITHIN THE CORE. THIS CHANGING FLUX THEN PASSES THROUGH THE SECONDARY WINDING, INDUCING AN AC VOLTAGE ACROSS IT. THE MAGNITUDE OF THIS INDUCED VOLTAGE IS DIRECTLY PROPORTIONAL TO HOW RAPIDLY THE MAGNETIC FLUX CHANGES AND THE NUMBER OF TURNS IN THE COIL.

FARADAY'S LAW OF INDUCTION

FARADAY'S LAW OF INDUCTION QUANTIFIES THIS RELATIONSHIP. IT STATES THAT THE INDUCED EMF ($\mathcal{E}$) IN ANY CLOSED CIRCUIT IS EQUAL TO THE NEGATIVE OF THE TIME RATE OF CHANGE OF THE MAGNETIC FLUX (Φ_B) THROUGH THE CIRCUIT. MATHEMATICALLY, THIS IS EXPRESSED AS $\mathcal{E} = -d\Phi_B/dt$. IN THE CONTEXT OF A TRANSFORMER, THE CHANGING CURRENT IN THE

PRIMARY COIL GENERATES A CHANGING MAGNETIC FLUX IN THE CORE. THIS FLUX LINKS WITH BOTH THE PRIMARY AND SECONDARY COILS. THE VOLTAGE INDUCED IN EACH COIL IS THEN DETERMINED BY THE NUMBER OF TURNS IN THAT COIL AND THE RATE OF CHANGE OF THIS MAGNETIC FLUX. IT'S THIS FUNDAMENTAL LAW THAT UNDERPINS THE ENTIRE OPERATION OF A TRANSFORMER.

THE FERROMAGNETIC CORE

THE FERROMAGNETIC CORE, USUALLY MADE OF LAMINATED IRON OR SILICON STEEL, PLAYS A VITAL ROLE IN EFFICIENTLY CHANNELING THE MAGNETIC FLUX GENERATED BY THE PRIMARY WINDING TO THE SECONDARY WINDING. WITHOUT IT, THE MAGNETIC FIELD WOULD DISSIPATE SIGNIFICANTLY INTO THE SURROUNDING AIR, GREATLY REDUCING THE EFFICIENCY OF INDUCTION. THE LAMINATIONS ARE CRUCIAL FOR MINIMIZING ENERGY LOSSES DUE TO EDDY CURRENTS, WHICH ARE INDUCED CURRENTS THAT CIRCULATE WITHIN THE CONDUCTIVE CORE MATERIAL AND DISSIPATE ENERGY AS HEAT. THE CORE ACTS AS A CONDUIT, ENSURING THAT ALMOST ALL THE MAGNETIC FLUX PRODUCED BY THE PRIMARY COIL LINKS WITH THE SECONDARY COIL, MAXIMIZING THE EFFECTIVENESS OF ELECTROMAGNETIC INDUCTION.

THE CORE TRANSFORMER EQUATION: VOLTAGE RELATIONSHIP

THE MOST FUNDAMENTAL EQUATION GOVERNING TRANSFORMER OPERATION DIRECTLY RELATES THE VOLTAGES ACROSS THE PRIMARY AND SECONDARY WINDINGS TO THE NUMBER OF TURNS IN EACH. FOR AN IDEAL TRANSFORMER, THIS RELATIONSHIP IS REMARKABLY SIMPLE AND INTUITIVE. IT STEMS DIRECTLY FROM FARADAY'S LAW OF INDUCTION. SINCE THE SAME CHANGING MAGNETIC FLUX LINKS BOTH WINDINGS (ASSUMING PERFECT FLUX LINKAGE), THE INDUCED VOLTAGE PER TURN IS IDENTICAL IN BOTH THE PRIMARY AND SECONDARY COILS. IF V_p AND V_s REPRESENT THE RMS VOLTAGES ACROSS THE PRIMARY AND SECONDARY WINDINGS, RESPECTIVELY, AND N_p AND N_s REPRESENT THE NUMBER OF TURNS IN THE PRIMARY AND SECONDARY WINDINGS, RESPECTIVELY, THE CORE VOLTAGE EQUATION IS:

$$V_p / N_p = V_s / N_s$$

THIS EQUATION TELLS US THAT THE RATIO OF THE PRIMARY VOLTAGE TO THE NUMBER OF PRIMARY TURNS IS EQUAL TO THE RATIO OF THE SECONDARY VOLTAGE TO THE NUMBER OF SECONDARY TURNS. THIS PROPORTIONALITY IS THE KEY TO VOLTAGE TRANSFORMATION. BY ADJUSTING THE NUMBER OF TURNS IN THE SECONDARY WINDING RELATIVE TO THE PRIMARY, WE CAN STEP UP OR STEP DOWN THE VOLTAGE.

STEP-UP AND STEP-DOWN TRANSFORMERS

A TRANSFORMER WHERE THE SECONDARY WINDING HAS MORE TURNS THAN THE PRIMARY WINDING ($N_s > N_p$) IS CALLED A STEP-UP TRANSFORMER. IN THIS CASE, THE SECONDARY VOLTAGE WILL BE HIGHER THAN THE PRIMARY VOLTAGE, AS INDICATED BY THE EQUATION $V_s = V_p (N_s / N_p)$. CONVERSELY, A TRANSFORMER WITH FEWER TURNS IN THE SECONDARY THAN THE PRIMARY ($N_s < N_p$) IS A STEP-DOWN TRANSFORMER, RESULTING IN A LOWER SECONDARY VOLTAGE: $V_s = V_p (N_s / N_p)$. THIS ABILITY TO PRECISELY CONTROL VOLTAGE LEVELS IS ESSENTIAL FOR EFFICIENT POWER TRANSMISSION OVER LONG DISTANCES (STEPPING UP VOLTAGE TO REDUCE CURRENT AND THUS MINIMIZE LINE LOSSES) AND FOR SAFELY DELIVERING POWER TO CONSUMERS AT USABLE VOLTAGE LEVELS (STEPPING DOWN).

THE IMPORTANCE OF AC VOLTAGE

IT IS CRITICALLY IMPORTANT TO NOTE THAT THIS EQUATION AND THE ENTIRE PRINCIPLE OF TRANSFORMER OPERATION ARE BASED ON ALTERNATING CURRENT (AC). A STEADY DIRECT CURRENT (DC) PRODUCES A CONSTANT MAGNETIC FIELD, WHICH, BY FARADAY'S LAW, DOES NOT INDUCE A VOLTAGE. THEREFORE, TRANSFORMERS CANNOT FUNCTION WITH DC POWER SUPPLIES. THE CHANGING NATURE OF AC IS WHAT DRIVES THE CHANGING MAGNETIC FLUX NECESSARY FOR INDUCTION. IF YOU WERE TO CONNECT A DC SOURCE TO A TRANSFORMER, THE PRIMARY WINDING WOULD ESSENTIALLY ACT AS A SHORT CIRCUIT, POTENTIALLY DAMAGING THE POWER SOURCE AND THE TRANSFORMER ITSELF.

THE ROLE OF THE TURNS RATIO

THE TURNS RATIO IS ARGUABLY THE MOST SIGNIFICANT PARAMETER IN DETERMINING HOW A TRANSFORMER ALTERS VOLTAGE AND CURRENT. IT IS DEFINED AS THE RATIO OF THE NUMBER OF TURNS IN THE SECONDARY WINDING TO THE NUMBER OF TURNS IN THE PRIMARY WINDING:

$$\text{Turns Ratio (A)} = N_s / N_p$$

THIS DIMENSIONLESS QUANTITY DIRECTLY DICTATES THE VOLTAGE TRANSFORMATION. USING THE CORE VOLTAGE EQUATION, WE CAN REWRITE IT IN TERMS OF THE TURNS RATIO:

$$V_s = V_p \cdot A$$

THIS EQUATION HIGHLIGHTS THE DIRECT PROPORTIONALITY BETWEEN THE SECONDARY VOLTAGE AND THE TURNS RATIO. IF THE TURNS RATIO IS GREATER THAN 1, THE VOLTAGE IS STEPPED UP. IF IT'S LESS THAN 1, THE VOLTAGE IS STEPPED DOWN. FOR EXAMPLE, A TRANSFORMER WITH A TURNS RATIO OF 5:1 (MEANING $N_s = 5 N_p$) WILL STEP UP THE VOLTAGE BY A FACTOR OF 5.

IMPACT ON IMPEDANCE

BEYOND VOLTAGE, THE TURNS RATIO ALSO INFLUENCES IMPEDANCE. THE IMPEDANCE "SEEN" FROM THE PRIMARY SIDE OF A TRANSFORMER IS RELATED TO THE IMPEDANCE ON THE SECONDARY SIDE BY THE SQUARE OF THE TURNS RATIO. THIS IS KNOWN AS IMPEDANCE TRANSFORMATION AND IS CRUCIAL FOR IMPEDANCE MATCHING IN ELECTRONIC CIRCUITS. FOR AN IDEAL TRANSFORMER, THE RELATIONSHIP IS:

$$Z_p = A^2 Z_s$$

WHERE Z_p IS THE PRIMARY IMPEDANCE AND Z_s IS THE SECONDARY IMPEDANCE. THIS PROPERTY ALLOWS ENGINEERS TO MATCH THE IMPEDANCE OF A SOURCE TO THE IMPEDANCE OF A LOAD TO MAXIMIZE POWER TRANSFER, A FUNDAMENTAL CONCEPT IN SIGNAL PROCESSING AND AUDIO AMPLIFICATION.

THE TRANSFORMER EQUATION FOR CURRENT

WHILE VOLTAGE IS TRANSFORMED DIRECTLY BY THE TURNS RATIO, CURRENT BEHAVES IN THE INVERSE MANNER IN AN IDEAL TRANSFORMER, ASSUMING CONSERVATION OF POWER. FOR AN IDEAL TRANSFORMER, THE POWER DELIVERED TO THE PRIMARY WINDING IS EQUAL TO THE POWER DELIVERED BY THE SECONDARY WINDING (IGNORING LOSSES). POWER (P) IN AN AC CIRCUIT IS GIVEN BY THE PRODUCT OF VOLTAGE (V) AND CURRENT (I), ASSUMING A POWER FACTOR OF 1 FOR SIMPLICITY IN THIS CONTEXT. THUS, FOR AN IDEAL TRANSFORMER:

$$P_p = P_s$$

$$V_p I_p = V_s I_s$$

REARRANGING THIS EQUATION TO SOLVE FOR THE PRIMARY CURRENT (I_p) OR SECONDARY CURRENT (I_s) AND SUBSTITUTING THE VOLTAGE RELATIONSHIP ($V_s = V_p \cdot A$), WE GET:

$$V_p I_p = (V_p \cdot A) I_s$$

$$I_p = A I_s$$

OR, EQUIVALENTLY:

$$I_s = I_p / A$$

THIS MEANS THAT IF THE VOLTAGE IS STEPPED UP BY THE TURNS RATIO ' A ', THE CURRENT IS STEPPED DOWN BY THE SAME RATIO ' A '. CONVERSELY, IF THE VOLTAGE IS STEPPED DOWN, THE CURRENT IS STEPPED UP. THIS INVERSE RELATIONSHIP IS CRITICAL FOR EFFICIENT POWER TRANSMISSION. BY STEPPING UP THE VOLTAGE FOR LONG-DISTANCE TRANSMISSION, THE CURRENT IS REDUCED, WHICH SIGNIFICANTLY MINIMIZES RESISTIVE LOSSES ($P_{\text{LOSS}} = I^2 R$) IN THE TRANSMISSION LINES.

POWER CONSERVATION IN IDEAL TRANSFORMERS

THE CONCEPT OF POWER CONSERVATION IS CENTRAL TO UNDERSTANDING THE CURRENT TRANSFORMATION. AN IDEAL TRANSFORMER HAS NO LOSSES; ALL THE ENERGY SUPPLIED TO THE PRIMARY COIL IS TRANSFERRED TO THE SECONDARY COIL. THIS MEANS THAT IF YOU INCREASE THE VOLTAGE, YOU MUST DECREASE THE CURRENT PROPORTIONALLY TO KEEP THE POWER CONSTANT, AND VICE-VERSA. THIS PRINCIPLE IS A DIRECT CONSEQUENCE OF THE CONSERVATION OF ENERGY AND IS FUNDAMENTAL TO THE FUNCTIONING OF ALL TRANSFORMERS, EVEN THOUGH REAL-WORLD TRANSFORMERS EXPERIENCE SOME ENERGY LOSSES.

IDEAL VS. REAL TRANSFORMERS: DEVIATIONS AND PRACTICAL CONSIDERATIONS

WHILE THE TRANSFORMER EQUATIONS PROVIDE A CLEAR AND ELEGANT FRAMEWORK FOR UNDERSTANDING VOLTAGE AND CURRENT TRANSFORMATION, THEY ARE BASED ON THE ASSUMPTION OF AN "IDEAL" TRANSFORMER. REAL-WORLD TRANSFORMERS, WHILE HIGHLY EFFICIENT, DO EXHIBIT CERTAIN LOSSES AND DEVIATIONS THAT AFFECT THEIR PERFORMANCE. UNDERSTANDING THESE DIFFERENCES IS CRUCIAL FOR ACCURATE DESIGN AND APPLICATION.

LOSSES IN REAL TRANSFORMERS

REAL TRANSFORMERS EXPERIENCE SEVERAL TYPES OF LOSSES:

- **COPPER LOSSES ($I^2 R$ LOSSES):** THESE ARE DUE TO THE ELECTRICAL RESISTANCE OF THE COPPER WINDINGS. AS CURRENT FLOWS THROUGH THE WIRES, HEAT IS GENERATED, REPRESENTING A LOSS OF ELECTRICAL ENERGY.
- **CORE LOSSES (IRON LOSSES):** THESE OCCUR WITHIN THE FERROMAGNETIC CORE AND CONSIST OF:
 - **HYSTERESIS LOSSES:** ENERGY IS LOST AS THE MAGNETIC DOMAINS WITHIN THE CORE MATERIAL ARE REPEATEDLY ALIGNED AND RE-ALIGNED BY THE ALTERNATING MAGNETIC FIELD.
 - **EDDY CURRENT LOSSES:** AS MENTIONED EARLIER, THESE ARE CIRCULATING CURRENTS INDUCED WITHIN THE CORE ITSELF BY THE CHANGING MAGNETIC FLUX. LAMINATED CORES HELP TO REDUCE THESE LOSSES BY INCREASING THE ELECTRICAL RESISTANCE PATH FOR THE EDDY CURRENTS.
- **STRAY LOSSES:** THESE ARE MINOR LOSSES THAT OCCUR DUE TO LEAKAGE FLUX AND OTHER EFFECTS NOT ACCOUNTED FOR IN THE IDEAL MODEL.

THESE LOSSES MEAN THAT THE POWER DELIVERED BY THE SECONDARY WINDING IS ALWAYS SLIGHTLY LESS THAN THE POWER SUPPLIED TO THE PRIMARY WINDING. THIS IS QUANTIFIED BY THE TRANSFORMER'S EFFICIENCY, WHICH IS TYPICALLY VERY HIGH (OFTEN OVER 95%) FOR POWER TRANSFORMERS.

LEAKAGE FLUX

IN AN IDEAL TRANSFORMER, IT'S ASSUMED THAT ALL THE MAGNETIC FLUX PRODUCED BY THE PRIMARY WINDING LINKS WITH THE SECONDARY WINDING, AND VICE VERSA. IN REALITY, SOME FLUX LINES ESCAPE AND DO NOT LINK BOTH COILS. THIS IS KNOWN AS LEAKAGE FLUX. LEAKAGE FLUX REDUCES THE EFFECTIVE COUPLING BETWEEN THE COILS AND CAN BE THOUGHT OF AS AN IMPEDANCE INHERENT TO THE TRANSFORMER ITSELF. IT AFFECTS BOTH VOLTAGE AND CURRENT RELATIONSHIPS, PARTICULARLY UNDER HEAVY LOAD CONDITIONS.

NON-LINEARITY AND SATURATION

THE MAGNETIC CORE OF A TRANSFORMER IS NOT PERFECTLY LINEAR. AT VERY HIGH MAGNETIC FLUX DENSITIES, THE CORE MATERIAL CAN BECOME SATURATED, MEANING IT CANNOT SUPPORT A FURTHER INCREASE IN FLUX. THIS CAN LEAD TO DISTORTION OF THE MAGNETIC FIELD AND AFFECT THE TRANSFORMER'S BEHAVIOR, PARTICULARLY WITH NON-SINUSOIDAL WAVEFORMS OR WHEN OPERATING AT OR NEAR ITS RATED CAPACITY.

APPLICATIONS OF TRANSFORMER EQUATIONS IN POWER SYSTEMS

THE TRANSFORMER EQUATIONS ARE NOT JUST THEORETICAL CONCEPTS; THEY ARE THE PRACTICAL TOOLS USED BY ELECTRICAL ENGINEERS TO DESIGN AND OPERATE THE VAST INTERCONNECTED POWER GRIDS THAT SUPPLY ELECTRICITY TO OUR HOMES AND INDUSTRIES. UNDERSTANDING HOW VOLTAGE AND CURRENT ARE TRANSFORMED IS PARAMOUNT FOR EFFICIENT AND SAFE POWER DISTRIBUTION.

POWER TRANSMISSION

AS DISCUSSED, THE PRIMARY APPLICATION OF TRANSFORMER EQUATIONS IN POWER SYSTEMS LIES IN POWER TRANSMISSION. GENERATORS PRODUCE ELECTRICITY AT A RELATIVELY LOW VOLTAGE. TO TRANSMIT THIS POWER OVER HUNDREDS OR THOUSANDS OF MILES, TRANSFORMERS ARE USED TO STEP UP THE VOLTAGE TO VERY HIGH LEVELS (E.G., HUNDREDS OF KILOVOLTS). THIS HIGH VOLTAGE, IN CONJUNCTION WITH THE INVERSE RELATIONSHIP FOR CURRENT, DRAMATICALLY REDUCES THE CURRENT FLOWING THROUGH THE TRANSMISSION LINES. LOWER CURRENT MEANS LOWER RESISTIVE LOSSES (I^2R), MAKING THE TRANSMISSION OF ELECTRICITY FAR MORE EFFICIENT AND ECONOMICAL. WITHOUT THIS STEP-UP TRANSFORMATION, A SIGNIFICANT PORTION OF THE GENERATED POWER WOULD BE LOST AS HEAT IN THE WIRES.

DISTRIBUTION NETWORKS

ONCE THE HIGH-VOLTAGE POWER REACHES SUBSTATIONS NEAR POPULATED AREAS, TRANSFORMERS ARE USED AGAIN, THIS TIME TO STEP DOWN THE VOLTAGE TO SAFER AND MORE MANAGEABLE LEVELS FOR DISTRIBUTION TO HOMES AND BUSINESSES. THESE SUBSTATIONS MIGHT HAVE MULTIPLE STAGES OF TRANSFORMERS, PROGRESSIVELY REDUCING THE VOLTAGE UNTIL IT REACHES THE STANDARD VOLTAGE USED BY APPLIANCES (E.G., 120V OR 240V IN NORTH AMERICA, 230V IN EUROPE). THE TRANSFORMER EQUATIONS ALLOW ENGINEERS TO PRECISELY CALCULATE THE REQUIRED VOLTAGE AND CURRENT TRANSFORMATIONS AT EACH STAGE OF THE DISTRIBUTION NETWORK.

INDUSTRIAL AND RESIDENTIAL USE

EVEN WITHIN OUR HOMES AND FACTORIES, TRANSFORMERS ARE UBIQUITOUS. SMALL TRANSFORMERS ARE FOUND IN POWER ADAPTERS FOR ELECTRONIC DEVICES (LIKE LAPTOPS AND PHONE CHARGERS) TO STEP DOWN MAINS VOLTAGE TO THE LOW DC VOLTAGES REQUIRED BY THESE DEVICES. IN INDUSTRIAL SETTINGS, TRANSFORMERS ARE USED TO MATCH VOLTAGES AND CURRENTS FOR SPECIFIC MACHINERY, ENSURING OPTIMAL PERFORMANCE AND SAFETY. THE FUNDAMENTAL TRANSFORMER EQUATIONS ARE THE UNDERLYING PRINCIPLES GUIDING THE DESIGN OF ALL THESE DEVICES, FROM MASSIVE GRID TRANSFORMERS TO TINY ELECTRONIC COMPONENTS.

FAQ SECTION

Q: WHAT IS THE CORE PRINCIPLE BEHIND HOW A TRANSFORMER WORKS?

A: THE CORE PRINCIPLE IS ELECTROMAGNETIC INDUCTION, WHERE A CHANGING MAGNETIC FIELD PRODUCED BY AN ALTERNATING CURRENT IN ONE COIL (THE PRIMARY) INDUCES A VOLTAGE IN ANOTHER COIL (THE SECONDARY) THROUGH A SHARED MAGNETIC CORE.

Q: HOW DOES THE TURNS RATIO AFFECT THE VOLTAGE IN A TRANSFORMER?

A: THE TURNS RATIO DIRECTLY DETERMINES THE VOLTAGE TRANSFORMATION. IF THE SECONDARY WINDING HAS MORE TURNS THAN THE PRIMARY, THE VOLTAGE IS STEPPED UP. IF IT HAS FEWER TURNS, THE VOLTAGE IS STEPPED DOWN, ACCORDING TO THE EQUATION $V_s / V_p = N_s / N_p$.

Q: IS IT POSSIBLE TO USE A TRANSFORMER WITH A DC POWER SOURCE?

A: NO, TRANSFORMERS CANNOT OPERATE WITH A DIRECT CURRENT (DC) SOURCE. A CONSTANT DC CURRENT PRODUCES A CONSTANT MAGNETIC FIELD, WHICH DOES NOT INDUCE A VOLTAGE. TRANSFORMERS RELY ON THE CHANGING MAGNETIC FIELD GENERATED BY ALTERNATING CURRENT (AC).

Q: WHAT HAPPENS TO THE CURRENT WHEN THE VOLTAGE IS STEPPED UP BY A TRANSFORMER?

A: IN AN IDEAL TRANSFORMER, WHEN THE VOLTAGE IS STEPPED UP, THE CURRENT IS STEPPED DOWN PROPORTIONALLY, ASSUMING POWER IS CONSERVED. THIS INVERSE RELATIONSHIP IS DESCRIBED BY THE EQUATION $I_p / I_s = N_s / N_p$.

Q: WHAT ARE THE MAIN TYPES OF LOSSES IN A REAL TRANSFORMER?

A: THE MAIN LOSSES IN A REAL TRANSFORMER ARE COPPER LOSSES (DUE TO RESISTANCE OF THE WINDINGS) AND CORE LOSSES, WHICH INCLUDE HYSTERESIS LOSSES AND EDDY CURRENT LOSSES WITHIN THE MAGNETIC CORE.

Q: WHY ARE TRANSFORMERS SO IMPORTANT FOR POWER TRANSMISSION?

A: TRANSFORMERS ARE CRUCIAL FOR POWER TRANSMISSION BECAUSE THEY ALLOW VOLTAGE TO BE STEPPED UP TO VERY HIGH LEVELS, WHICH SIGNIFICANTLY REDUCES CURRENT AND THUS MINIMIZES ENERGY LOSS DUE TO RESISTANCE IN THE LONG TRANSMISSION LINES.

Q: CAN A TRANSFORMER CHANGE THE FREQUENCY OF THE AC POWER?

A: NO, A TRANSFORMER DOES NOT CHANGE THE FREQUENCY OF THE AC POWER. THE FREQUENCY OF THE VOLTAGE INDUCED IN THE SECONDARY WINDING IS THE SAME AS THE FREQUENCY OF THE VOLTAGE APPLIED TO THE PRIMARY WINDING.

Q: WHAT IS IMPEDANCE TRANSFORMATION IN A TRANSFORMER?

A: IMPEDANCE TRANSFORMATION IS THE ABILITY OF A TRANSFORMER TO CHANGE THE IMPEDANCE OF A CIRCUIT. THE IMPEDANCE SEEN ON ONE SIDE OF THE TRANSFORMER IS RELATED TO THE IMPEDANCE ON THE OTHER SIDE BY THE SQUARE OF THE TURNS RATIO ($Z_p = a^2 Z_s$), WHICH IS VITAL FOR IMPEDANCE MATCHING.

[Transformer Equation Physics](#)

Transformer Equation Physics

Related Articles

- [transparent physics definition](#)
- [uci physics 2](#)
- [uc davis physics major](#)

[Back to Home](#)